

Technical Manual



02.012.01

**REMOVE AND INSTALL
FOOT BRAKE ASSEMBLY**

STARK FUTURE



SAFETY WARNINGS

Observe your local health and safety guidelines. Ensure a safe working environment. Wear appropriate protective gear. Deviating from the prescribed order may result in injury or damage to the products.



TOOLS

- HEX 8
- TRX 30
- ALN 10
- HEX 13



OPERATION TIME

22 Minutes

REMOVAL



WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Remove the rear wheel.
Refer to:



09.015.01

[Remove and Install rear wheel ↗.](#)

- 2 Remove the foot brake master cylinder. Refer to:



02.027.01

[Remove and Install foot brake master cylinder ↗.](#)

- 3 Grab the rear brake caliper and the foot brake master cylinder and clear the brake hose from the swingarm brake line bracket.

3

INSTALLATION



WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Grab the rear brake caliper and the foot brake master cylinder and fit the hose onto the swingarm brake line bracket.
- 2 Secure the rear brake caliper.
- 3 Install the foot brake master cylinder.
Refer to:



02.027.01

Remove and Install foot brake master cylinder ↗.

- 4 Install rear wheel. Refer to:



09.015.01

Remove and Install rear wheel ↗.



WARNING

Check brakes operation before operating the bike.

starkfuture.com

ENG 2023-07

Copyright © 2023 Stark Future SL. All rights reserved.
Reproduction, even in part, as well as copying of all kinds,
is permitted only with the express written permission
of the copyright owner.

STARK FUTURE