

Technical Manual



**02.027.01**

**REMOVE AND INSTALL  
FOOT BRAKE MASTER CYLINDER**

**STARK FUTURE**



## SAFETY WARNINGS

Observe your local health and safety guidelines. Ensure a safe working environment. Wear appropriate protective gear. Deviating from the prescribed order may result in injury or damage to the products.



## TOOLS

TRX 30



## OPERATION TIME

6 Minutes

---

# REMOVAL

---



## WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Hold the foot pedal spring.
- 2 Unscrew the pedal link bolt.



## NOTE

Beware of falling objects.

- 3 Unscrew the foot brake master cylinder bolts.
- 4 Remove the master cylinder.

---

# INSTALLATION

---



## WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Hold the foot brake master cylinder in place.
- 2 Tighten the foot brake master cylinder bolts to **10 Nm**.
- 3 Assemble the brake pedal link.
- 4 Hold the assembled brake pedal link in place.
- 5 Tighten the brake pedal link bolt to **10 Nm**.



## WARNING

Check brakes operation before operating the bike.

starkfuture.com

ENG 2023-07

Copyright © 2023 Stark Future SL. All rights reserved.  
Reproduction, even in part, as well as copying of all kinds,  
is permitted only with the express written permission  
of the copyright owner.

**STARK FUTURE**