

Technical Manual



04.028.01

**REMOVE AND INSTALL
FRONT CONNECTORS BOX**

STARK FUTURE



SAFETY WARNINGS

Observe your local health and safety guidelines. Ensure a safe working environment. Wear appropriate protective gear. Deviating from the prescribed order may result in injury or damage to the products.



TOOLS

- Cutting pliers
- TRX 30



CONSUMABLES

Zip tie



OPERATION TIME

20 Minutes

REMOVAL



WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Disconnect the handlebar controls.
Refer to:



06.030.07

Disconnect and reconnect handlebar controls ↗.

- 2 Carefully cut the zip tie holding the main wiring harness to the front connectors box.
- 3 Gently remove the front connectors box from between the triple clamps.

INSTALLATION



WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Install the front connectors box in place between the triple clamps in the top triple clamp opening.
- 2 Fit a zip tie to hold the main wiring harness onto the connectors box.



NOTE

Leave enough wiring length on the sockets side to avoid pulling any wires out of the sockets.

- 3 Connect the handlebar controls.
Refer to:



06.030.07

Disconnect and reconnect handlebar controls ↗.



WARNING

Turn ON the bike and connect to the Stark phone to check battery status and that the bike is operating normally after disconnecting electronic components.

starkfuture.com

ENG 2023-08

Copyright © 2023 Stark Future SL. All rights reserved.
Reproduction, even in part, as well as copying of all kinds,
is permitted only with the express written permission
of the copyright owner.

STARK FUTURE